

Scanned and Prepared by
Dale H. Cook

BULLETIN T-105
January 24, 1951

FUSE IN BIAS CIRCUIT

This Tube Tester is equipped with a fuse in the Grid Bias Circuit as a protection for the Bias Potentiometer in case an attempt is made to test a shorted tube.

NOTE: ALWAYS MAKE SHORT CHECK BEFORE MAKING QUALITY TEST.

The fuse is mounted in the main control panel where it is readily visible.

A burned out bias fuse lamp will result in failure of the mutual conductance meter to read when the Gm button is pressed. If the fuse lamp burns out, replace only with a No.49 Panel Lamp.

THE HICKOK ELECTRICAL INSTRUMENT COMPANY
10514 Dupont Avenue
Cleveland 8, Ohio